

DOUBLE BIKER TIDY

Contents:

- 1 x Wall Bracket
- 1 x Top Shelf
- 1 x Bottom Shelf with Baskets and Hanging Rail
- 4 x Shelf Supports
- 8 x 6mm x 20mm Shelf Support Bolts
- 2 x Jacket Hangers
- 2 x Trouser Hangers
- 1 x Full Suit Hanger
- 1 x Bag of Wall Fixings



Fitting Instructions:

1. Fix "Wall Bracket" to wall using fixings provided using a 7mm masonry drill. **Please assess the suitability of the fixings provided for your wall – we cannot be held responsible if the fixings supplied do not suit your property as there are many different types of construction.**
2. Attach "Shelf Supports" to wall bracket using the 6mm x 20mm Bolts, do not over tighten.
3. Slot "Bottom Shelf" into position, holding at an angle (with the lug on the shelf on the underneath) place on to hooks through mesh and lower.
4. Repeat the above with the "Top Shelf".
5. Fix "Shelf Support" on to shelves. Do not tighten until all four are in place, then tighten all eight bolts.
6. The Jacket and Trouser Hangers hang on to the hanging rail and the Full Suit hanger hangs on to the edge of either shelf.

Colour of trouser clips may vary.

Occasionally the red clips can become detached from the black trouser clip. These can be reattached by simply clicking back on.