

MULTI-PURPOSE BIKER TIDY

Contents:

- 1 x Hinged Bottom Double Frame
- 1 x Top Frame
- 20 x Shelf Supports
- 34 x 6mm x 20mm Shelf Support Bolts
- 8 x Adjustable Feet

One Side:

- 1 x Top Shelf
- 1 x Bottom Shelf including Baskets and Hanging Rail
- 2 x Jacket Hangers
- 2 x Trouser Hangers
- 1 x Full Suit Hanger
- 1 x Hook

Other Side:

- 6 x Shelves



Fitting Instructions:

- 1 Unfold Hinged Double Base Frame on to floor and screw in the adjustable feet.
- 2 Attach "Shelf Supports" to frame and mesh floor shelf using the 6mm x 20mm Bolts, do not over tighten.
- 3 Slide top frame into hinged bottom frame.
- 4 Slot "Bottom Shelf" into position, holding at an angle (with the lug on the shelf on the underneath) place on to hooks through mesh and lower.
- 5 Repeat the above with the "Top Shelf". Repeat on the other side.
- 6 Fix "Shelf Support" on to shelves do not tighten until all eight are in place then tighten all bolts.
- 7 Adjust feet on floor to suit your surface.
- 8 The Jacket and Trouser Hangers hang on to the hanging rail and the Full Suit hanger hangs on to the edge of either shelf.

Colour of trouser clips may vary. Occasionally the red clips can become detached from the black trouser clip. These can be reattached by simply clicking back on.